




PARTS & SERVICE DEPARTMENT
 Nashville, Tennessee
 615-889-8900 • Fax: 615-547-1000
 www.Lochinvar.com

Replacement Parts List

**Charger DV
 Commercial Gas
 DNR, DLR / DNA, DLA Models**



ITEM #	PART #	DISCRIPTION	MODEL #
1	PVT1040	INDUCED DRAFT BLOWER	ALL
2	WTR1090	DIP TUBE (80 Gal.)	DN(L)R(A)199-080 & 301-080
2	WTR1091	DIP TUBE (100 Gal.)	DN(L)R(A)199-100 & 360-100
3	PRS1020	PRESSURE SWITCH	DN(L)R(A)199-080 to 301-100
3	PRS1021	PRESSURE SWITCH	DN(L)R(A)360
4	RLV1014	T & P RELIEF VALVE	DN(L)R(A)199-080 & 100
4	RLV1015	T & P RELIEF VALVE	DN(L)R(A)301-080 to 360-100
5	JKT1215	FLUE BAFFLE	ALL
6	WTR1040	CLEANOUT ACCESS COVER	ALL
7	DRV2508	DRAIN VALVE	ALL
8	GKT1010	GASKET, HANDHOLE	DN(L)R199, 300, & 360
8	GKT1017	GASKET, HANDHOLE (ASME)	DN(L)A199, 301, & 361
9	BNR1059	BURNER, MAIN	ALL
10	PLT1120	PILOT ASSEMBLY, NAT	DNR(A)199 to 360
10	PLT1121	PILOT ASSEMBLY, LPG	DLR(A)199 to 360
11	MAN1021-7	MANIFOLD, BURNER	ALL
12	VAL1041	VALVE, NATURAL GAS	DNR(A)199 to 360
12	VAL1065	VALVE, LP GAS	DLR(A)199 to 360
13	ORF1020-42	ORIFICE	DNR(A)199
13	ORF1020-52	ORIFICE	DLR(A)199
13	ORF1020-33	ORIFICE	DNR(A)300, 301
13	ORF1020-49	ORIFICE	DLR(A)300, 301
13	ORF1020-31	ORIFICE	DNR(A)360, 361
13	ORF1020-47	ORIFICE	DLR(A)360, 361
14	TRF1038	TRANSFORMER	ALL
15	RLY1134	IGNITION MODULE	ALL
16	RLY1140	BLOWER RELAY	ALL
17	SWT1000	MAIN POWER SWITCH	ALL
18	TST1294	TSAT CONTROL BOARD	ALL
19	JKT1200	UTILITY COVER - GRAY	ALL
20	WTR1085	ANODE ROD	ALL
21	TST1191	TSTAT POTENTIOMETER	ALL
22	TST1096	KNOB FOR POTENTIOMETER	ALL
23	TST1187	UPPER TEMP SENSOR	ALL
24	TST1188	LOWER TEMP SENSOR	ALL
25	WTR1080	OUTLET NIPPLE	ALL
26	JKT3003	PILOT SHIELD	ALL
-	MSC2706	TUBING EDPM (order by ft.)	ALL
27	JKT1215	BURNER ACCESS PANEL	ALL
28	MSC1110	BURNER SIGHT GLASS	ALL
29	MSC1111	SIGHT GLASS BACKING PLATE	ALL
30	GKT1110	SIGHT GLASS GASKET	ALL
31	GKT1111	SIGHT GLASS GROMMET	ALL
32	GKT1115	GASKET KIT, BURNER ACCESS	ALL
33	DRH1085	VENT ADAPTER	ALL
34	GKT1112	GASKET, BLOWER & VENT	ALL
-	DRH1160	SILICONE	ALL
35	DRH1087	FLANGE, COMB. BOX	ALL
36	DRH1088	COMBUSTION AIR INLET TUBE	ALL
37	DRH1089	AIR INLET BOOT	ALL
-	WRE1055	LOWER SENSOR WIRE HARN	DN(L)R(A)199-080, 301-080
-	WRE1056	LOWER SENSOR WIRE HARN	DN(L)R(A)199-100, 301-100, & 361-100
-	WRE1057	WIRE HARNESS BLOWER	ALL
-	WRE1058	WIRE HARNESS PSI SWITCH	ALL
38	DRH1171	VENT KIT ASSEMBLY 6"	DN(L)R(A)199
39	DRH1173	VENT KIT ASSEMBLY 8"	DN(L)R(A)300, 301, 360, & 361
40	DRH1175	VENT EXTENSION TUBE 39"	DN(L)R(A)199
41	DRH1176	VENT EXTENSION TUBE 39"	DN(L)R(A)300, 301, 360, & 361
-	DRH1177	VENT TERMINAL FLAT ROOF	DN(L)R(A)199
-	DRH1178	VENT TERMINAL SLOPE ROOF	DN(L)R(A)199
-	DRH1179	VENT TERMINAL FLAT ROOF	DN(L)R(A)300, 301, 360, & 361
-	DRH1180	VENT TERMINAL SLOPE ROOF	DN(L)R(A)300, 301, 360, & 361
42	DRH1181	VENT ELBOW 8"	DN(L)R(A)300, 301, 360, & 361
43	DRH1182	VENT ELBOW 6"	DN(L)R(A)199

Please provide model & serial number when ordering parts.