





PARTS & SERVICE DEPARTMENT
Nashville, Tennessee
615-889-8900 • Fax: 615-882-2918
parts_team@lochinvar.com
www.Lochinvar.com

Replacement Parts List


Power-Fin®
Heating Boilers &
Hot Water Supply Boilers
PB/PF 1501, 1701, 2001




CONTROL PANEL



HEAT EXCHANGER ASSEMBLY



GAS TRAIN ASSEMBLY



ITEM NO.	PART NO.	DESCRIPTION	MODEL NO.
CONTROLS			
1	100145022	FAN REPLACEMENT ASSEMBLY	PB/PF 1501-2001
2	100166222	SWITCH, PRESSURE BEFORE D08	PB/PF 1501-2001-M9
2	100208376	SWITCH, PRESSURE AFTER D08	PB/PF 1501-2001-M9
2	100166223	SWITCH, PRESSURE BEFORE D08	PB/PF 1501/2001-B9
2	100208380	SWITCH, PRESSURE AFTER D08	PB/PF 1501/2001-B9
2	100166224	SWITCH, PRESSURE BEFORE D08	PB/PF 1701-B9
2	100166108	SWITCH, PRESSURE AFTER D08	PB/PF 1701-B9
3	100208498	CONNECTION BOARD	ALL
4	100208461	BOARD, CONTROL, USER INTERFACE	ALL
5	100208494	BOARD, CONTROL, MAIN	ALL
6	100208509	RELAY, PUMP	ALL
7	100208495	RELAY, 24VAC COIL	ALL
8	100208242	SWITCH, ON, OFF	ALL
9	100208174	HIGH LIMIT W/MANUAL RESET	ALL PB
9	100208179	HIGH LIMIT AUTO RESET	ALL PF
10	100208152	GAUGE, TEMPERATURE AND PRESSURE	ALL PB
11	100208448	VALVE, PRESSURE RELIEF, 1", 50#	PB 1501/1701
11	100208442	VALVE, PRESSURE RELIEF, 3/4", 50#	PB 2001
11	100208453	VALVE, T & P RELIEF, 1", 150#	All PF
12	100208653	SWITCH, FLOW	ALL
GAS TRAIN ASSEMBLIES			
13	100135330	MAIN BURNER ASSEMBLY	PF/PB 1501
13	100135331	MAIN BURNER ASSEMBLY	PF/PB 1701
13	100135332	MAIN BURNER ASSEMBLY	PF/PB 2001
14	100208332	SIGHT GLASS, 1/2"	ALL
15	100165937	IGNITOR, HOT SURFACE KIT	ALL
16	100208087	GASKET, IGNITER	ALL
17	100208102	GASKET, BURNER, FAN	ALL
18	100208094	GASKET, BURNER	ALL
19	100172024	GAS VALVE ASSEMBLY, NAT	PF/PB 1501
19	100172025	GAS VALVE ASSEMBLY, NAT	PF/PB 1701
19	100172026	GAS VALVE ASSEMBLY, NAT	PF/PB 2001
19	100171939	GAS VALVE ASSEMBLY, LP	PF/PB 1501
19	100171940	GAS VALVE ASSEMBLY, LP	PF/PB 1701
19	100171941	GAS VALVE ASSEMBLY, LP	PF/PB 2001
20	100171780	VALVE, VENTURI	PF/PB 1501-1701
20	100171763	VALVE, VENTURI	PF/PB 2001
21	100233698	GASKET FAN, VENTURI	ALL
22	100208105	GASKET, GAS TRAIN	ALL
23	100171912	VALVE, BALL, 1.5"	ALL
24	100169749	FLANGE, GAS 1 1/4" NPT	ALL
HEAT EXCHANGERS			
25	100173872	FLANGE	ALL
26	100233672	GASKET, TOP HEADER FLANGE 1/4"	ALL
27	100147436	HEAT EXCHANGER (HLW)	PF 1501
27	100147437	HEAT EXCHANGER (HLW)	PF 1701
27	100147438	HEAT EXCHANGER (HLW)	PF 2001
27	100147444	HEAT EXCHANGER (H)	PB 1501
27	100147445	HEAT EXCHANGER (H)	PB 1701
27	100147446	HEAT EXCHANGER (H)	PB 2001
28	100141598	DRAIN VALVE KIT	PB
28	100141604	DRAIN VALVE KIT	PF

PLEASE HAVE MODEL NUMBER AND SERIAL NUMBER WHEN ORDERING PARTS.

ITEM NO.	PART NO.	DESCRIPTION	MODEL NO.
MISCELLANEOUS (CONTINUED)			
29	100233613	BULBWELL, EMMEN CONTROL	ALL
30	100233695	BULBWELL, HIGH LIMIT	ALL
31	100153827	V-BAFFLE, HEAT EXCHANGER (24)	PF/PB 1501
31	100153828	V-BAFFLE, HEAT EXCHANGER (24)	PF/PB 1701
31	100153829	V-BAFFLE, HEAT EXCHANGER (24)	PF/PB 2001
32	100154193	RETAINER ,V-BAFFLE	ALL
33	100208063	FILTER, AIR, HEAVY DUTY	ALL
34	100233489	FAN, VENTILATION	ALL
35	100208337	CONDENSATE TRAP	ALL
36	100208552	THERMISTOR SENSOR	ALL
37	100135503	3/4X3/8 BRASS BUSHING	ALL
-	100157742	OUTDOOR AIR SENSOR	ALL
-	100170647	FLUE SENSOR	ALL
-	100163160	ALUMINUM TUBING (Order by the foot)	ALL
-	100171006	TUBING, EPDM 3/8" (Order by the foot)	ALL
PUMPS			
-	100133622	PUMP ASSEMBLY	PF
JACKET/DOOR ASSEMBLIES			
38	100153852	JACKET TOP, WITHOUT VENTILATION FAN	ALL
39	100154374	JACKET, OUTER FRONT UPPER LEFT	ALL
40	100154396	JACKET, OUTER FRONT LOWER	PF/PB 1501
40	100154397	JACKET, OUTER FRONT LOWER	PF/PB 1701
40	100154398	JACKET, OUTER FRONT LOWER	PF/PB 2001
41	100153938	JACKET, OUTER RIGHT	PF/PB 1501
41	100153939	JACKET, OUTER RIGHT	PF/PB 1701
41	100153940	JACKET, OUTER RIGHT	PF/PB 2001
42	100154399	JACKET, OUTER LEFT	PF/PB 1501
42	100154400	JACKET, OUTER LEFT	PF/PB 1701
42	100154401	JACKET, OUTER LEFT	PF/PB 2001
INSULATION			
-	100145460	INSULATION, SIDES	PF/PB 1501
-	100145461	INSULATION, SIDES	PF/PB 1701
-	100145462	INSULATION, SIDES	PF/PB 2001
-	100145580	INSULATION, BACK	PF/PB 1501
-	100145581	INSULATION, BACK	PF/PB 1701
-	100145582	INSULATION, BACK	PF/PB 2001
-	100145447	INSULATION, FRONT	PF/PB 1501
-	100145448	INSULATION, FRONT	PF/PB 1701
-	100145449	INSULATION, FRONT	PF/PB 2001
-	100145450	INSULATION, FRONT DOOR	PF/PB 1501
-	100145451	INSULATION, FRONT DOOR	PF/PB 1701
-	100145452	INSULATION, FRONT DOOR	PF/PB 2001
PLEASE HAVE MODEL NUMBER AND SERIAL NUMBER WHEN ORDERING PARTS.			